



Padded Radiator Install Instructions

This manual has been written to help you install the Padded Radiator Surround. Failure to follow this advice may result in damage to the product.

Safety Notice

This instruction guide is not meant for electric or element type radiators. These radiators should not have safety padding as this could cause a fire risk.

Measuring

When measuring for the Radiator, ensure that you have considered any surrounding obstructions (pipes, skirting etc) to ensure an excellent fit. The padded radiator surround should consider the following;

- **Left & Right:** bigger on both sides (10cm-15cm). This might be bigger as this depends on your thermostat.
- **Top:** Consider the window ledge (5-10cm bigger)
- **Front:** Coming out towards the room to allow ventilation: 10cm
- Consider skirting thickness for a tight fit. This might need to be removed.



Installing Guidance

Remove the front mesh panel for access to fix the attached fittings.

Put two corner bracket fittings (**15 x 75 x 75mm**) on both sides on the inner side of the radiator padded surround. Fittings should be towards the radiator to ensure they are not showing. Then mark up position on the wall and fix via wall plugs provided.



Once the Radiator is fitted to the wall securely, put the front panel on via the velcro.

Any additional guidance, please feel free to contact Sense Sensory Ltd.



Sense Sensory

Tel: 01702 810016 info@sensesensory.co.uk www.sensesensory.co.uk